



ICE-LINED REFRIGERATOR

Quality compressor, strong refrigeration capacity.
 Bandy pipes refrigeration, never leakage.
 Temperature display instrument is equipped outside the Ice-lined refrigerator, convenient observation of temperature change inside the cabinet.
 The temperature inside the cabinet is suitable for storage of pharmacy-cortical products and vaccine.
 Top open single door provides flexible and convenient opening, effective reductive reduction of loss cold air, saving energy.
 The ambient temperature is 43, the temperature inside cabinet is still maintained between 0 and 8.
 90mm extra thick insulation reduces effectively loss of cold air and provides energy saving.
 Accumulation of cool by ice-row with features of big capacity of accumulation of cool, long hold over time, The temperature inside cabinet is still maintained between 0 and 10, even if over 30 hours after power cut out.
 Start up with low voltage, especially suitable for us in the area with poor power supply.
 Two layers door sealing device and thick insulation design provide better performance of insulation.
 Corrosive resistance pattern aluminum of interior provides smooth and clean plate surface good effect on heat exchange and not easy corrosion.



Specifications:

Model	YBC-80B	YBC-180B
Type	Chest	Chest
Capacity	80L	180L
Store temperature	0oC~8oC	0oC~8oC
Rated voltage (V)	~220	~220
Frequency (Hz)	50	50
Rated input power (W)	230W	330W
Power consumption (kW.h/24h)	0.75	1.15
Anti-stock Protection class	I/B	I/B
Climatic class	T	T
Mode of Condenser	Natural cooling	Natural cooling + Air cooling
Refrigerant	R134a	R134a
Refrigerant charging	80g	170g
Net/Gross Weight	85kg/95kg	120kg/130kg
External dimension WxDxH (mm)	1064x620x880	1125x710x925
Packing dimension WxDxH (mm)	1128x636x1020	1187x726x1049